

Video call Busy line field Free calling Presence Unified communications Programmable buttons Voice mail Conferencing Parallell ringing Chat Calling line Virtual collaboration Mobility Easy call

Application Desktop Customer portal Mobility HD voice video call Chat

Speed dial buttons

Panasonic

Operation of buttons with indication of occupancy for quick dialing of telephones Panasonic KX-HDV230, KXHDV330 a KX-HDV430



Assembling and connecting the extension panel - Panasonic KX-HDV230, KX-HDV330 and KX-HDV430 phones only

In the package with the speed dial panel, you will find the **KX-HDV20** panel itself, a cable to connect to the **KX-HDV230 / KX-HDV330 / KX-HDV430** telephone, a stand for the panel and a set for screwing. Screw the plastic element from this set from the bottom of the phone into the prepared holes using the included screws, and similarly from the bottom of the panel. The connection to the phone is made with the included cable to the "Ext" socket on the phone side, and "Ext in" on the panel side. If you are going to connect more panels, use the "Ext out" and "Ext in" sockets to connect them. Assembling the individual panels together is the same as assembling the telephone - 1st panel. If more modules will be used (max. 6), the power supply must be connected to module No. 2 (in the direction from the phone).



